



Optical Sensor Installation Instruction

The sensor is secured to the actuator cap [2] using the button-head cap screws [1A] supplied with the sensor kit [1]. The plastic bolt retainers can be left in place, and will fit into the recessed holes on the sensor cap when installed.

Using a 3/32 in. hex wrench, tighten both button-head cap screws [1-A] to a torque of approximately 10-30 in·lbs.

Optical sensors kits are factory set to the correct depth and tested for proper functionality.

