



# Swagelok PTFE-Free Pipe Thread Sealant

## Application

1. Remove oil, grease, and other contaminants from pipe threads.
2. Knead tube before use to blend contents.
3. Remove cap from ribbon applicator.
4. Apply PTFE-free pipe thread sealant to fill the entire male thread engagement area. Use a solvent such as acetone to remove any excess sealant.
5. Assemble the fitting.
6. Replace cap before storing tube.



**⚠ Use with metal pipe threads only.**

**⚠ Do not use Swagelok PTFE-free pipe thread sealant in systems containing a strong oxidizer. A chemical reaction, including spontaneous combustion, can occur.**

Swagelok—TM Swagelok Company  
© 2003 Swagelok Company  
Printed in U.S.A., CP  
August 2003  
MS-CRD-PTFEF, Revision 0