

PB Series Rubber Hose Assembly and Disassembly

Swagelok®

Assembly

1. Cut a clean, square edge on the end of the hose.



2. Cover the first barb of the end connection with the hose.

Note: Lubricating the end connection barbs with a light oil (i.e. 10W40) may ease assembly.



3. Hold the end connection against a flat surface. Grip the hose and push with a steady force until the hose seats into the blue finishing cap.

⚠ Do not use a hose clamp.

⚠ Ensure hose is pushed fully into finishing cap.



Disassembly

1. Slit the hose lengthwise from the blue finishing cap to the end of the barb. Do not damage the barbs.



2. Bend the hose to expose the barbs, then remove the hose with a quick pull.

⚠ Do not reuse hose.

