



## PTFE Thread Sealant

Note: 1/4 in. wide tape should be used on 1/8, 1/4, and 3/8 in. male tapered pipe threads. 1/2 in. wide tape should be used on 1/2 in. and larger male tapered pipe threads. Tape should be used **only** on male tapered pipe threads. **Do not use on flared, coned, or tube fitting ends.**

### How to Apply

1. Thoroughly clean male and female threads, assuring the removal of all previously applied antiseize compound or tape.
2. Wrap tape in the direction of thread spiral of male pipe thread beginning with first thread. Tape should **never** extend beyond or overhang the first thread as tape could shred and get into fluid system.
3. While keeping the edge of the tape parallel to the face of the fitting, wrap two to three revolutions of tape.
4. Draw the free end around the threads tautly so that it conforms to the threads.
5. Cut or tear off excess tape.
6. If the tape does not lie flat, firmly press the tape into the threads.

Material conforms to Commercial Item Description A-A-58092.

