


Swagelok

Plug Installation Instruction

(plugs unused port of
Swagelok® tube fitting)



Make subsequent connections by slightly tightening with wrench after tightening the nut by hand.

While holding the fitting body steady, tighten the plug one-quarter turn from the finger-tight position.

1/16, 1/8 and 3/16 in.; 2, 3, and 4 mm tube fittings, tighten one-eighth turn.

Swagelok — TM Swagelok Company
© 2008 Swagelok Company
Printed in U.S.A., CP
July 2008, R2
MS-12-11

www.swagelok.com