



www.swagelok.com

MS-INS-60-4

“60” Series Vinyl Sleeve Assembly Instructions

1. Remove old sleeve from handle.

NOTE: If sleeve is difficult to remove, it may be necessary to cut the sleeve off with a sharp instrument.

2. To put new sleeve on, immerse sleeve in approximately 130°F (54°C) tap water until soft or pliable. Quickly, slide the sleeve onto the handle. Make sure there is no excess sleeve hanging over the end of the handle.

(The Swagelok logo should be visible on top of the handle).

NOTE: Once the sleeve begins to cool, it is more difficult to slide on.

© 1986, 2000 Swagelok Company