

## **BV Series Bleed Valves**

## A CAUTION

When installing a BV series bleed valve, position the vent tube so that system fluid is directed **away** from operating personnel. **Always open bleed valves slowly**. These valves contain **no packing**, therefore some fluid weepage will occur when the valves are opened. Operating personnel must take suitable measures to protect themselves from exposure to system fluids.

## **P** Series Purge Valves

## A CAUTION

When installing a P series purge valve, position the vent hole so that system fluid is directed **away** from operating personnel. The vent hole rotates with the cap, changing the direction of discharge as the cap is turned. **Always open purge valves slowly.** These valves contain **no packing**, therefore some fluid weepage will occur when the valves are opened. Operating personnel must take suitable measures to protect themselves from exposure to system fluids.

www.swagelok.com

© 2010 Swagelok Company 2-2010, Rev E MS-INS-BV/P