GSL2


Simple Liquid Sampler with Purge


Panel Recommendations

- Used in general liquid sampling applications. Purge option clears sample fluid before and/or after sample collection.
- Recommended for non-toxic liquids that may settle in the sampler.



Flow Schematic







Swagelok London

Liquid Bottle Sampler




Simple Liquid Sampler with Purge

Panel Operation

- 1. Insert and secure bottle in fixture.
- 2. Switch Sample Valve to SAMPLE position.
- 3. Hold valve open on fixture to take sample.
- 4. After dispensing sample, release valve on fixture.
- 5. Switch Sample Valve to PURGE position.
- 6. Hold valve open on fixture to purge.
- 7. Adjust Purge Pressure and Purge Flow as necessary.
- 8. Release valve on fixture.
- 9. Switch Sample Valve to OFF position.
- 10. Remove bottle from fixture.








CASE NO.

NO. GSL-2

REV -



BILL OF MATERIAL PART NUMBER DESCRIPTIO QTY. DESCRIPTION MVS SAMPLE VALVE, 320Z BOSTON SS-MVS-32OZ-32-S4-S4-VI 1 ROUND (SENTRY) VAF-G2-05L-1-0-WZ G2 MODEL FLOWMETER, .1 - 1.0 NL/M AIR 1 KPR1CJA412A60000 KPR SERIES REGULATOR, 0-10 PSIG 1 PGI-63S-BG1-BAQX-G S MODEL GAUGE, 0-1 BARG 1 CH SERIES CHECK VALVE 1 43G SERIES 3-WAY BALL VALVE 1 304-GSL-PANEL-24 MOUNTING PANEL, 304 SS 1 BULKHEAD BRACKET, 304 SS 1 2" PIPE CLAMP, 304 SS 2 1/4-20 x 3/8" BHCS, 18-8 SS 2 #6-32 x 1/4" BHCS, 18-8 SS 7 2 #8-32 x 1/4" BHCS, 18-8 SS 400 SERIES BULKHEAD UNION 5 400 SERIES ADAPTER ELBOW 1 400 SERIES MALE ELBOW 1 400 SERIES UNION TEE 1 400 SERIES MALE CONNECTOR 1 1/4" TA MALE ADAPTER 2 400 SERIES UNION ELBOW 2 1/4" X .035 SS TUBING 112.91 in.

	TITLE	
r-3-17	LIQUID GRAB SAMPLE PANEL	
	NO. GSL-2	REV -