GSM-L-1(-P)


Standard Liquid Sampler with Purge

Panel Recommendations


- Used in general liquid sampling applications. Purge option (using gas or solvent) clears fluid before and/or after sample collection.
- Recommended for fluids that are toxic or may settle in the sampler.
- Suggested for systems when the return is sent to flare.



Flow Schematic



Valve Schematic





Swagelok London


Liquid Cylinder Sampler

GSM-L-1(-P) Standard Liquid Sampler with Purge

Panel Operation

- 1. Turn Sample Valve to VENT position and Purge Valve to OFF position.
- 2. Connect sample cylinder to quick connect on panel.
- 3. Hold cylinder and close clamp to secure.
- 4. Connect hose to cylinder.
- 5. Open cylinder valves and turn Sample Valve to SAMPLE position.
- 6. Allow fluid to flow until cylinder is full.
- 7. Turn Sample Valve to OFF position and close cylinder valves.
- 8. Turn Sample Valve to VENT postition and Purge Valve to ON position.
- 9. Purge System, then turn Purge Valve to OFF position.
- 10. Disconnect hose from cylinder.
- 11. Hold cylinder, open clamp, disconnect quick connect on panel and remove cylinder.





<u>ART NUMBER</u>	DESCRIPTION	<u>QTY.</u>
ALVE-2	43G SERIES 2-VALVE GEARED ASSEMBLY	1
ETA	R SERIES RELIEF VALVE	1
S4-GR	42G SERIES 3-WAY BALL VALVE	1
l	CH SERIES CHECK VALVE	1
G10-BAQX-G	s model gauge, 0-10 barg	1
-400	QC4 SERIES QUICK CONNECT STEM	1
1-400	QC4 SERIES QUICK CONNECT BODY	1
TA4-30	FL4 SERIES HOSE, 30" LONG	1
	400 SERIES UNION TEE	4
<u>`</u>	400 SERIES PORT CONNECTOR	3
-4	400 SERIES REDUCER ELBOW	4
	400 SERIES BULKHEAD UNION	6
PANEL-P	MOUNTING PANEL, 304 SS	1
BRKT-8	BULKHEAD BRACKET, 304 SS	1
BRKT-5	2" Cylinder bracket, 304 SS	1
BRKT-2	QC4 QUICK CONNECT BRACKET, 304 SS	1
	TOGGLE CLAMP, 300 SERIES SS	1
	2" PIPE CLAMP, 304 SS	2
6	BHCS. 6-32 X .25 in.	7
3	#8-32 x 1/4" BHCS, 18-8 SS	4
2	1/4-20 x 3/8" BHCS, 18-8 SS	10
5-20-S	1/4" x .035" 316/316L TUBING	155.66 in

r-6-17	SMAPLE GRAB MOUDLE	
	NO. GSM-L-1-XXX-XXXP-S4 REV -	